



Anziehvorschrift für Zylinderkopf		279.532	 Das Original	
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a GM		
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
 906.110 M 14x1,5x155				
Anziehen/ Tightening/ Serrage/ Apriete	Without captured washers 30 Nm * ➤ 85° ➤ 85° ➤ 85°		With captured washers 30 Nm * ➤ 110° ➤ 110° ➤ 110°	
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Ø: 95,3 mm; $\frac{1}{2}$: 1,10 mm				
Mot: LWN 2,8 ltr.				
Colorado, Express/Savana				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*279.532*	