



Anziehvorschrift für Zylinderkopf		424.091		
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
				
802.800 M 12x1,5x147				
Anziehen/ Tightening/ Serrage/ Apriete	* 10 Nm ● 100 nm ● 3 min □ 180° 70 Nm ➤ 120°			
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
-/1,42 mm ÷				
1,8 Ltr. Diesel, Mot.D18NA, 44 kW (60 PS) Fiesta, Escort, Orion ab 07/1992>				
1,8 Ltr. Turbo-Diesel, Mot.D18T,D18TI 55/66 kW (75/90 PS) Fiesta, Escort, Orion, Sierra ab 07/1992>				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*424.091*	