



Anziehvorschrift für Zylinderkopf		018.050 passend für / suitable for adaptable à / adaptable a VW / AUDI	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
 130.110 M12x1,5x159				
Anziehen/ Tightening/ Serrage/ Apriete		* 35 Nm ➤ 60 Nm ➤ 90° ➤ 90°		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
✱ 1,1 mm, Ø 84 mm, 1 Loch/hole/trou/agujero Cyl. 4-6				
Mot.: ASB, BKN, BKS, BMK, BNG, BPP, BSG, CAPA 2,7 ltr./3,0 ltr. V6 Diesel				
A4, A5, A6, A8, Q7 Phaeton, Touareg				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*018.050*	