

Anziehvorschrift für Zylinderkopf		081.581 passend für / suitable for adaptable à / adaptable a Opel / Saab	 Das Original
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			

Schraubenkopf / Head shape
 Tête de vis / Cabeza de tornillo
 

257.910
M 11x1,5x162

Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete

9	5	1	3	7
8	4	2	6	10

Anziehen/
 Tightening/
 Serrage/
 Apriete

*	30 Nm
➤	75°
➤	80°

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor
 Ø 87,05 mm
 Mot.: Z20NER, Z20NET, B207E, B207L, B207R
 Signum, Vectra, Cadillac BLS, Saab 9-3, 9-5

ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601	*081.581*
--	------------------