



Anziehvorschrift für Zylinderkopf		124.634 passend für / suitable for adaptable à / adaptable a Volkswagen	 Das Original
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
057.290 M 11x1,5x101/131			
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤	30 Nm 60 Nm 90° 90°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
✚ 0,64 mm, Ø 82,5 mm			
Mot.: AMV, AQP, AUE, AXK, AYL, BDE, BDF 2,8 Ltr. VR6 150 kW (204 PS)			
Alhambra, Bora, Golf, Leon, Sharan, Toledo, T4 Ford Galaxy			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*124.634*	