


Anziehvorschrift für Zylinderkopf		130.742 passend für / suitable for adaptable à / adaptable a Citroën, Peugeot	 Das Original
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
 152.550 M 12x1,5x123			
Anziehen/ Tightening/ Serrage/ Apriete	* 20 Nm 60 Nm ➤ 90° ➤ 90°		
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ □ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
✚ 1,62 mm, Ø 84 mm, 4 Löcher/holes/trous/agujeros			
Mot.: DW8, DW8B, 1WZ, WJY, WJZ 1,9 Ltr. Diesel 44-51 KW			
Berlingo, C15, Jumpy, Xsara, 206, 207, 306, Expert, Partner Fiat Scudo, Toyota Corolla			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*130.742*	