

Anziehvorschrift für Zylinderkopf		144.420 passend für / suitable for adaptable à / adaptable a Fiat	 Das Original										
Tightening Instructions for Cylinder Head													
Instructions de serrage pour culasse													
Prescripciones de apriete para culatas													
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete											
		<table border="1"><tr><td>⑧</td><td>⑥</td><td>②</td><td>⑤</td><td>⑩</td></tr><tr><td>⑦</td><td>③</td><td>①</td><td>④</td><td>⑨</td></tr></table>		⑧	⑥	②	⑤	⑩	⑦	③	①	④	⑨
⑧	⑥	②	⑤	⑩									
⑦	③	①	④	⑨									
760.720 M 9x1,25x96													
Anziehen/ Tightening/ Serrage/ Apriete	100.GL.000 020.AA.090 * 50 Nm	100.GL.3000 146.A.000 100.GL * 30 Nm 59 Nm 1.000 km ☐ 59 Nm											
Zeichenerklärung / Explanations / Explication / Explicacion													
*	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves emplar tornillos nuevos										
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C) calentamiento (80°C)										
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis aflojar y apretar tornillo a tornillo										
●	Setzzeit	relaxation time	durée de tassement tiempo de espera										
➤	Drehwinkel	torque angle	angle de serrage ángulo de giro										
Motortyp / Engine type / Type de moteur / Tipo de motor													
⚙ 1,74/1,65 mm, Ø 66 mm													
Mot.: 100 G.000, 100 GL3.000, 146 A.000 0,9 Itr.													
Fiat 127, 850, Fiorino, Panda, Uno Seat Ibiza, Marbella, Terra													
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*144.420*											