



Anziehvorschrift für Zylinderkopf		150.021	 Das Original	
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a VW/AUDI		
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
 057.260 M 12x166-10.9				
Anziehen/ Tightening/ Serrage/ Apriete		* 40 Nm ➤ 60 Nm ➤ 90° ➤ 90°		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
✱ 1,6l mm, Ø 80,7 mm, 3 Löcher/holes/trous/agujeros				
Mot.: AMF, ATL, BAY, BHC, BMS, BNM, BNV 1,4 ltr. TDI				
A2, Arosa, Ibiza, Fabia, Roomster, Polo				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*150.021*	