

Anziehvorschrift für Zylinderkopf		150.801 passend für / suitable for adaptable à / adaptable a VW/AUDI	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
 057.240 M12x166-10.9				
Anziehen/ Tightening/ Serrage/ Apriete		* 30 Nm 60 Nm ➤ 90° ➤ 90°		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
2,0 Ltr. TDI 91, 100, 103 kW (124,136,140 PS) ✚ 1,65mm 3 Löcher, Holes, Trous, Agujeros, Fori Mot. BMM, BGW, BHW, BMP, BVH, BRT, BPW, BRC, BSS BWW, CBKA, CBHA, CBJB				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*150.801*	