

Anziehvorschrift für Zylinderkopf		157.744																	
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a GM																	
Instructions de serrage pour culasse																			
Prescripciones de apriete para culatas																			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete																	
		<table><tr><td>15</td><td>13</td><td>11</td><td>12</td><td>14</td></tr><tr><td>10</td><td>3</td><td>1</td><td>5</td><td>9</td></tr><tr><td>7</td><td>6</td><td>2</td><td>4</td><td>8</td></tr></table>			15	13	11	12	14	10	3	1	5	9	7	6	2	4	8
15	13	11	12	14															
10	3	1	5	9															
7	6	2	4	8															
Anziehen/ Tightening/ Serrage/ Apriete	M11 Pos. 1-10: 30 Nm ➤ Pos. 1-10: 90° ➤ Pos. 1-10: 70°	M8 Pos. 11-15: 30 Nm																	
Zeichenerklärung / Explanations / Explication / Explicacion																			
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos															
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)															
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo															
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera															
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro															
Motortyp / Engine type / Type de moteur / Tipo de motor																			
Ø: 104 mm; $\frac{1}{2}$: 1,33 mm																			
Mot: LS3, L99, L92, LY6, L76 LC8, L96, L94, L9H 6,0 - 6,2 ltr. V8																			
Escalade, Camaro, Caprice, Silverado, Tahoe, Sierra																			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*157.744*																