

Anziehvorschrift für Zylinderkopf		245.660	 Das Original																
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a Audi																	
Instructions de serrage pour culasse																			
Prescripciones de apriete para culatas																			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete																	
 586.360 M 12x1,5x175		<table><tr><td>⑦</td><td>①</td><td>④</td><td>⑥</td></tr><tr><td>⑤</td><td>③</td><td>②</td><td>⑧</td></tr><tr><td>⑤</td><td>③</td><td>②</td><td>⑧</td></tr><tr><td>⑦</td><td>①</td><td>④</td><td>⑥</td></tr></table>		⑦	①	④	⑥	⑤	③	②	⑧	⑤	③	②	⑧	⑦	①	④	⑥
⑦	①	④	⑥																
⑤	③	②	⑧																
⑤	③	②	⑧																
⑦	①	④	⑥																
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤	35 Nm 70 Nm 90° 90°																	
Zeichenerklärung / Explanations / Explication / Explicacion																			
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro																
Motortyp / Engine type / Type de moteur / Tipo de motor																			
3,0 TDI 1,64 mm links/left																			
Mot. CVUA, CVUB, CVUC, DEHA 235/240/250 KW (320/326/340 PS)																			
A6, A6 allroad, A7, SQ5																			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*245.660*																	