



Anziehvorschrift für Zylinderkopf		287.500		
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Ford		Das Original
Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete				
				
802.870 M 10x1,5x102				
Anziehen/ Tightening/ Serrage/ Apriete	* 20-30 Nm 40-50 Nm ➤ 90°-120°			
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Ø: 81,6 mm; $\frac{1}{4}$: 0,64 mm				
MC: EYDB; EYDC; EYDD; EYDE; EYDFEYDG; EYDI; EYDJ EYDL; EYPA; EYPC; RKB; RKF; RKH; RKJ; RKK 1,8 ltr. Zetec 85 KW (115 PS)				
Focus 11/98➔ Transit Connect 05/02➔				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*287.500*	