

Anziehvorschrift für Zylinderkopf		300.733	 Das Original																				
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a																					
Instructions de serrage pour culasse																							
Prescripciones de apriete para culatas		Mercedes-Benz																					
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete																					
		<table><tr><td>10</td><td>6</td><td>2</td><td>4</td><td>8</td></tr><tr><td>9</td><td>5</td><td>1</td><td>3</td><td>7</td></tr><tr><td>9</td><td>5</td><td>1</td><td>3</td><td>7</td></tr><tr><td>10</td><td>6</td><td>2</td><td>4</td><td>8</td></tr></table>		10	6	2	4	8	9	5	1	3	7	9	5	1	3	7	10	6	2	4	8
10	6	2	4	8																			
9	5	1	3	7																			
9	5	1	3	7																			
10	6	2	4	8																			
718.630 M12 x 1,5 x 201,5																							
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤	20 Nm 60 Nm 90° 90°																					
Zeichenerklärung / Explanations / Explication / Explicacion																							
✱	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos																			
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)																			
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo																			
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera																			
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro																			
Motortyp / Engine type / Type de moteur / Tipo de motor																							
OM 628.960 W220 / S400CDI OM 628.961 W211 / E400CDI OM 628.962 W463 / G400CDI OM 628.963 W163 / M400CDI																							
rechts/right																							
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*300.733*																				