



Anziehvorschrift für Zylinderkopf		331.740 passend für / suitable for adaptable à / adaptable a Peugeot	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
				
152.550 M 12x1,5x123				
Anziehen/ Tightening/ Serrage/ Apriete	* 35 Nm 70 Nm ➤ 160°			
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Fiat Ulysse		ab 1994-2002		
Lancia Zeta		ab 1995-2002		
Peugeot 406, 605, 806		ab 1992>		
Citroen XM, Xanita, Evasion		ab 1992>		
Mot. XU10J2TE, XU10J2TE/Z, RGX, RGY				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*331.740*		