



Anziehvorschrift für Zylinderkopf		338.861 passend für / suitable for adaptable à / adaptable a Renault	 Das Original
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
373.281 M 11x1,5x126 E18			
Anziehen/ Tightening/ Serrage/ Apriete	* 25 Nm 25 Nm ➤ 270° +/-10°	Kangoo * 25 Nm 25 Nm ➤ 225° +/-10°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
Ø: 77,5 mm; $\frac{1}{2}$: 0,7 mm			
Mot: K9K 714, 718, 740, 766, 768, 800 1,5 ltr. dCi 47-63 kW (64-86 PS)			
Clio, Twingo, Modus, Kangoo			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*338.861*	