



Anziehvorschrift für Zylinderkopf		340.310	 Das Original	
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a Porsche		
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
				
872.290 M 12x1,5x140				
Anziehen/ Tightening/ Serrage/ Apriete	* □ ➤ ➤	5 Nm 50 Nm 4 Nm 12 Nm 65° 65°		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
✱ 1,64 mm, Ø 104,3 mm, Cyl. 1-3				
Mot.: MA1.71/75/76, MDA.BA, MDB.CA, MDG.GA MDH.NA 3,8 ltr./4,0 ltr.				
911 Turbo (997/991), 911 GT2/GT3 (991)				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*340.310*	