

Anziehvorschrift für Zylinderkopf		353.273		
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		passend für / suitable for adaptable à / adaptable a BMW Das Original		
		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
527.450 M10x1,5x170		7 5 1 3 9 10 4 2 6 8		
Anziehen/ Tightening/ Serrage/ Apriete	M10x170 30 Nm ➤ 90° ➤ 90° ➤ 45°	M9x95/ M9x125 30 Nm ➤ 90° ➤ 45°		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Mot. N43 B16 Ø 82,8mm ± 0,5mm E81/E87 116i E90/E91/E92 316i				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*353.273*		