



Anziehvorschrift für Zylinderkopf		431.321 passend für / suitable for adaptable à / adaptable a PSA	 Das Original
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
267.550 M 12x1,5x126			
Anziehen/ Tightening/ Serrage/ Apriete	* 22 Nm 60 Nm 360° 60 Nm ➤ 220°	Citroen: Jumper	* 22 Nm 60 Nm 360° 60 Nm ➤ 110° ➤ 110°
		Peugeot: Boxer	* 22 Nm 60 Nm 360° 60 Nm ➤ 110° ➤ 110°
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ □ ● ➤	neue Zylinderkopf-schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
Ø 86 mm, $\frac{1}{8}$ 1,25 mm, 1 Loch			
Mot: 4HY, DW12UTED 2,2 Ltr. HDi 74 kW (101 PS)			
Boxer, Jumper		ab 2002➔	
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*431.321*	