


Anziehvorschrift für Zylinderkopf		458.112 passend für / suitable for adaptable à / adaptable a Chrysler / Dodge / Jeep	 Das Original
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
Anziehen/ Tightening/ Serrage/ Apriete		* ➤ M12: 34 Nm ➤ M12: 54 Nm ➤ M12: 90° M8: 20 Nm M8: 20 Nm (check) M8: 34 Nm	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
5.7 L OHV, 16 Valve; V8			
Mot.: EZC, EZD, EZH installation position: right			
Chrysler 300 / Dodge Challenger, Charger, Durango, Ram 1500, 2500, 3500 Jeep Grand Cherokee			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*458.112*	