


Anziehvorschrift für Zylinderkopf		471.740	 Das Original
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a Chevrolet/Daewoo	
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
356.390 M10x1,25x166			
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤ ➤	Pos. 1-10: 25 Nm Pos. 1-10: 70° Pos. 1-10: 70° Pos. 1-10: 50°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
Ø: 80 mm; $\frac{1}{8}$: 0,55 mm			
Mot: F14D3, F16D3 1.4 ltr-1.6 ltr			
Chevrolet Aveo, Cruze, Kalos, Lacetti, Nubira Daewoo Kalos, Lacetti, Nubira			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*471.740*	