


Anziehvorschrift für Zylinderkopf		505.650	
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a PSA Peugeot/Citroën	
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
642.100 M12x1,25x224,5			
Anziehen/ Tightening/ Serrage/ Apriete	* ➤	20 Nm 40 Nm 80 Nm 180°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
Peugeot 607		ab 2004➔	
Peugeot 407		ab 2005➔	
Citroën C6		ab 2005➔	
Citroën C5		ab 2008➔	
Mot.: DT17TED4/UHZ 2,7 Ltr. HDi			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*505.650*	