



Anziehvorschrift für Zylinderkopf		537.930		
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		passend für / suitable for adaptable à / adaptable a		
		Opel		
		Das Original		
		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
273.150 M12x146/175				
Anziehen/ Tightening/ Serrage/ Apriete	* M12x146x1,5 40 Nm 90° 90°	* M12x175x1,5 40 Nm 120° 120°		
Zeichenerklärung / Explanations / Explication / Explicacion				
*	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
1,20 mm 2 Kerben rechts				
Mot. Z30DT				
135 KW (184PS)				
Vectra C, Signum				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*537.930*	