


Anziehvorschrift für Zylinderkopf		732.311	 Das Original
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a VW / Skoda / Seat	
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
189.610 M 12x1,75x137			
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤	30 Nm 50 Nm 90° 90°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
✚ 1,63 mm			
1,2 Ltr. 3 Cyl TDI			
Mot. CFWA 55 kW (75 PS)			
Polo, Fabia, Roomster, Ibiza			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*732.311*	