


Anziehvorschrift für Zylinderkopf		752.789		
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		passend für / suitable for adaptable à / adaptable a	Toyota	Das Original
Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete				
				
708.200 M 10 x 97				
Anziehen/ Tightening/ Serrage/ Apriete	* 25 Nm 45 Nm 53 - 64 Nm			
Zeichenerklärung / Explanations / Explication / Explicacion				
✳	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
82,0 mm Ø				
Carina II AT 151 Mot.4AL 6/1985>1987				
Celica AT 160 Mot.4AL 6/1985>1987				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*752.789*		