

Anziehvorschrift für Zylinderkopf		763.845		
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		passend für / suitable for adaptable à / adaptable a		
		Opel		
		Das Original		
Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete				
A  B 		9 5 1 3 7 10 6 2 4 8		
Anziehen/ Tightening/ Serrage/ Apriete		B Innentorx Mot. 14137012 > M11x105x1,25 Elring-ZKS 803.010		
* ➤ 65° ➤ 65° ➤ 65° ★ 15 min ➤ 30°-45°		* 25 Nm ➤ 90° ➤ 90° ➤ 90°		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
86 Ø				
Mot. 20 XE, C 20 XE, 4 Cyl., 2,0 l (DOHC) 16V				
110 kW (150 PS)				
Kadett-E 1988>				
Vectra 10/1988>				
Calibra 09/1989>				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*763.845*		