



Anziehvorschrift für Zylinderkopf		774.847	 Das Original	
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a BMW		
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
 802.720 M 12 x 157				
Anziehen/ Tightening/ Serrage/ Apriete		* 58 - 62 Nm ● 15 min ➤ 30° - 36° ★ 25 min ➤ 20° - 30°		
Zeichenerklärung / Explanations / Explication / Explicacion				
★	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Mot. M10/M20 B18/B20 ±1,5mm				
1800, 2000, 2000C,CS,ti,tii,tilux				
1802, 2002, 2002tii, 2002ti,tii, 2002turbo				
E21 316, 318, 318i, 320, 320i				
E30 316, 316i, 318i				
E12 518, 518i, 520, 520i				
E28 518, 518i				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*774.847*	