


Anziehvorschrift für Zylinderkopf		809.760 passend für / suitable for adaptable à / adaptable a Opel	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
				
803.050 M 12x1,5x102				
Anziehen/ Tightening/ Serrage/ Apriete	Y17DT/Y17DTL * 20 Nm ➤ 40 Nm ➤ 60° ➤ 13° ➤ 60° ➤ 13°	Z17DTH/Z17DTL * 15 Nm ➤ 39 Nm ➤ 60° ➤ 60°		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Mot. Y17DT, Y17DTL, Z17DTL, Z17DTH				
Corsa C, Astra G, Astra H, Meriva				
✱ 1,45 mm (3 Loch/hole)				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*809.760*	