


Anziehvorschrift für Zylinderkopf		825.395	 Das Original	
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a Opel		
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
				
820.297 M 11 x 154				
Anziehen/ Tightening/ Serrage/ Apriete	* 25 Nm ➤ 90° ➤ 90° ➤ 45° ★ 15 min ➤ 30° ➤ 15°			
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
82,5 Ø				
1,5 mm ÷ 2 Löcher / Holes				
Mot. 1,7 l, Diesel (OHC), 4 Cyl. 42 kW (57 PS)				
YD (OHC)				
Kadett, Vectra 10/1988>, Astra 9/1991>				
Astra Diesel 1989>, Belmont Diesel 1989>,				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*825.395*		