

Anziehvorschrift für Zylinderkopf		831.434 passend für / suitable for adaptable à / adaptable a Daimler	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
12 8 4 2 6 10 14 11 7 3 1 5 9 13				
Anziehen/ Tightening/ Serrage/ Apriete		M 12 * 40 Nm 60 Nm 80 Nm * 80°C 90 Nm	M 8 * 25 Nm	
Zeichenerklärung / Explanations / Explication / Explicacion				
*	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
82 Ø				
Mot. M.B. 127.981, 3/1963→1/1967				
M.B. 129.980/981, norm. V.9,5:1				
M.B. 129.982. Benzin,, 8/1965→1/1968				
230/6 SL, 250 SE, 250 SL				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*831.434*	