

Anziehvorschrift für Zylinderkopf	843.863 passend für / suitable for adaptable à / adaptable a Opel/Saab/Fiat	 Das Original
Tightening Instructions for Cylinder Head		
Instructions de serrage pour culasse		
Prescripciones de apriete para culatas		

Schraubenkopf / Head shape
 Tête de vis / Cabeza de tornillo
 

Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete

10	6	2	4	8
7	3	1	5	9

Anziehen/
 Tightening/
 Serrage/
 Apriete

✱	65 Nm
➤	90°
➤	90°
➤	90°

Zeichenerklärung / Explanations / Explication / Explicacion

✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

1,9 Ltr. JTD 1,02 mm

Opel Mot: Z19DTH / Z19DTJ 110 KW / 150 PS
 Astra H, Signum, Vectra C, Zafira B

Saab 9-3 Mot: Z19DTH 110 KW / 150 PS

ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601	*843.863*
--	------------------