



Anziehvorschrift für Zylinderkopf		913.864 passend für / suitable for adaptable à / adaptable a Mercedes-Benz	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
 820.114 M 10x80/102/115				
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤	10 Nm 35 Nm 90° 90°	M 8: 25 Nm	
Zeichenerklärung / Explanations / Explication / Explicacion				
* ★ □ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage	emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
90 mm Ø 1,74 mm ÷				
E 290 Turbodiesel (W210) 290 GDT 212 D, 312 D, 412 D, T1N Sprinter 512 D, 612 D, 812 D T2W Vario				
M.B.602.982 M.B.602.983 M.B.602.980 M.B.602.984				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*913.864*	