


Anziehvorschrift für Zylinderkopf		917.908 passend für / suitable for adaptable à / adaptable a Volkswagen	 Das Original
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
104.510 M 1x85/119/144			
Anziehen/ Tightening/ Serrage/ Apriete	* 40 Nm 60 Nm ➤ 90° ➤ 90°		
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ □ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
Mot. 2,8 Ltr. VR6 / 2,9 Ltr. VR6 T4 Transporter 1/1996> Golf,Vento 1/1992> Passat 10/1993> Sharan,Ford Galaxy 9/1995> Golf Syncro 11/1994> Passat Syncro 10/1994>			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*917.908*	