

Anziehvorschrift für Zylinderkopf		925.750	 Das Original
Tightening Instructions for Cylinder Head		passend für / suitable for	
Instructions de serrage pour culasse		adaptable à / adaptable a	
Prescripciones de apriete para culatas		Renault	
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	



373.320
M 12x1,5x131

10	6	2	3	7
9	5	1	4	8

Anziehen/ Tightening/ Serrage/ Apriete	* 5 Nm (Pos. 1-10) 30 Nm (Pos. 1-10) ➤ 300° ±6° (Pos. 1-10)
---	---

Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor				
Ø: 85,85 mm; $\frac{\pi}{8}$: 1,15 mm				
Mot: M9T				
Renault Master dCi, Opel Movano				

ElringKlinger AG, Max-Eyth-Str.2
72581 Dettingen / Erms. Tel. 07123/724 601

925.750