

Montageinformation / Information for Mounting

MAPCO-No. 91852 + 91853



DEU

Umbauen des Original-Schutzrohrs und der Originalbefestigung am Zylinderrohr notwendig.



ESP

Recuperar del resorte original el tubo de protección y original el anclaje del lado tubo.



FRA

Réutiliser la fixation originale tube de protection et originale montée sur le tube dur vérin à gaz.



GBR

Recover the protection tube and the tube side fitment from original Gas Spring.



NLD

Bij ombouw de originele beschermbuis en de originele bevestiging onderdelen overzetten.