

## Solution








New

Old

New

New



(SWAG 50 92 1855). The former semi-circular design has now been changed to a flat design identical to the original part (see picture 3). This means the mounting clamp must also be changed. The stabilizer mounts and clamps (SWAG 50 92 7355) should always be replaced in pairs to ensure a professional level of servicing.

fitting the stabilizer mounting

## Stabilizer mounting repair kit (with clamps) SWAG 50 92 7400

This repair kit contains stabilizer mounts with matching mounting clamps as well as the required high tensile mounting screws (10.9 grade).

So you have everything you need to fit stabilizer mounts quickly!

New



repair kit SWAG 50 92 7400

Ask your SWAG partner for SWAG spare parts! All parts are also available on www.swag.de.