

DONNEES TECHNIQUES

Fonctionnement	Wastegate
Commande	pneumatique
Restriction du fabricant	BW - KKK
Type de turbo	Simple
Accessoires	avec joints

PHOTOS



DOCUMENTS

BT-183 Instructions de montage turbos (AST)

APPLICATIONS

AUDI		
A3 (96-03) (8L1) - 1.8 T	150 ch	12.1996 >
	180 ch	12.1998 >
A3 (96-03) (8L1) - 1.8 T quattro	150 ch	12.1996 >
	180 ch	10.1998 >
TT (98-06) (8N3) - 1.8 T	180 ch	10.1998 >
TT (98-06) (8N3) - 1.8 T quattro	180 ch	10.1998 >
TT (98-06) Roadster (8N9) - 1.8 T	180 ch	10.1999 >
TT (98-06) Roadster (8N9) - 1.8 T quattro	180 ch	02.2000 >
SEAT		
LEON (98-06) (1M1) - 1.8 20V T 4	180 ch	11.1999 >
VOLKSWAGEN		
BORA (1J2) - 1.8 T	150 ch	05.2000 > 05.2005
BORA Break (1J6) - 1.8 T	150 ch	05.2000 > 05.2005
GOLF (97-05) (1J1) - 1.8 T	150 ch	08.1997 > 06.2005
GOLF (99-05) Break (1J5) - 1.8 T	150 ch	05.2000 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.