



Anziehvorschrift für Zylinderkopf		040.554 passend für / suitable for adaptable à / adaptable a Fiat/Lancia	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
 760.720 M 9x1,25x96				
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤	20 Nm 30 Nm 90° 90°		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor ✱ 0,49 mm, 72,4 mm Mot.: 169 A4.000, 199 A4.000 350 A1.000 1,2 ltr.-1,4 ltr. 8V Mito, 500, Doblo, Idea, Musa, Palio, Panda, Punto, Qubo, Siena, Strada, Ypsilon				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*040.554*		