


Anziehvorschrift für Zylinderkopf		076.358 passend für / suitable for adaptable à / adaptable a Fiat/Lancia/Opel	 Das Original
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤	40 Nm 90° 90°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ □ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
✚ 0,82 mm, Ø 70,6 mm, 1 Loch/hole/trou/agujero/foro			
Mot.: 188A9.000, Y13DT, Z13DT, Z13DTJ, Z13DTH 1,3 ltr. Diesel JTD			
500, Doblo, Nuova Panda, Idea, Doblo, Palio, Punto, Siena Ypsilon, Musa Astra, Agila, Combo, Corsa, Meriva			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*076.358*	