



Anziehvorschrift für Zylinderkopf Tightening Instructions for Cylinder Head Instructions de serrage pour culasse Prescripciones de apriete para culatas		152.820 passend für / suitable for adaptable à / adaptable a Toyota	 Das Original												
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete													
 708.240 M 12 x 107/126															
<table border="0"> <tr> <td>Anziehen/</td> <td>✱</td> <td>38 Nm</td> </tr> <tr> <td>Tightening/</td> <td></td> <td>78 Nm</td> </tr> <tr> <td>Serrage/</td> <td>➤</td> <td>90°</td> </tr> <tr> <td>Apriete</td> <td>➤</td> <td>90°</td> </tr> </table>				Anziehen/	✱	38 Nm	Tightening/		78 Nm	Serrage/	➤	90°	Apriete	➤	90°
Anziehen/	✱	38 Nm													
Tightening/		78 Nm													
Serrage/	➤	90°													
Apriete	➤	90°													
Zeichenerklärung / Explanations / Explication / Explicacion															
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos											
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)											
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo											
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera											
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro											
Motortyp / Engine type / Type de moteur / Tipo de motor Ø: 93,5; ⅜: 1,65 Mot: 2L, 2L-T 2,4 ltr. 55-66 kW (75-90 PS) Hiace III-IV, Hilux, Land Cruiser Taro															
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*152.820*													