

Anziehvorschrift für Zylinderkopf		180.180		
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		passend für / suitable for adaptable à / adaptable a Fiat Das Original		
		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete ⑧ ⑥ ② ⑤ ⑩ ⑦ ③ ① ④ ⑨		
760.720 M 9 x 96				
Anziehen/ Tightening/ Serrage/ Apriete	156C.046 176A6.000 176B2.000 (Punto)	160A3.000 176B2.000 156C.046(Y10 89-95)		
✱	20 Nm	✱ 30 Nm		
➤	30 Nm	➤ 90°		
➤	90°	➤ 90°		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
÷ 1,95 mm, Ø 71 mm				
Tipo, Uno, Y10 1,1 Ltr.		ab 1988>		
Panda, Punto 1,1 Ltr.		ab 1991>		
Cinquecento 1,1 Ltr.		ab 1994>1998		
Seicento 1,1 Ltr.		ab 1998>2000		
Mot. 176B2.000, 156C.046, 176A6.000,				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*180.180*		