

Anziehvorschrift für Zylinderkopf		182.790 passend für / suitable for adaptable à / adaptable a Subaru	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
③ ① ⑥ ⑤ ② ④				
Anziehen/ Tightening/ Serrage/ Apriete	* 29 Nm 69 Nm ☐ 1 - 2: 34 Nm ☐ 3 - 6: 15 Nm ➤ 1 - 6: 90° ➤ 1 - 6: 90°			
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Durchm. 89,0 mm Mot. EJ16 1,6i 4WD 1597 ccm SOHC 16V Impreza GC, GF 1992- Mot. EJ18 1,8i 4WD 1820 ccm SOHC 16V Legacy BC, BGF 1989- Impreza GC, GF 1992-				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*182.790*	