

Anziehvorschrift für Zylinderkopf		187.710	
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a	
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Fiat	Das Original



152.760
M 12x1,25x218

9	7	1	3	5	11
12	6	4	2	8	10

Anziehen/ Tightening/ Serrage/ Apriete	*	Fiat: 20 Nm 65 Nm ➤ 90° ➤ 90° ➤ 90°	Lancia: * 65 Nm ➤ 90° ➤ 90° ➤ 90°
---	---	--	---

Zeichenerklärung / Explanations / Explication / Explicacion

✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

83 mm Ø 1,80 mm ± 2 Löcher

Mot: 182.A2.000, 838.A3.000, 838.A7.000
2,4 TD

Marea ab 1996 ➔
Kappa 07/1996 ➔ 10/2001

ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601	*187.710*
--	------------------