

Anziehvorschrift für Zylinderkopf		529.600 passend für / suitable for adaptable à / adaptable a Toyota	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
⑦⑤②④⑩ ⑨③①⑥⑧				
Anziehen/ Tightening/ Serrage/ Apriete		* 20 Nm 40 Nm 53 Nm		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Celica Liftback (T16) 2.0 GT 08.85-08.89 110 KW				
Celica (ST16_) 2.0 01.87-08.90 110 KW				
Celica Coupe (T16F) 2.0 08.87-08.89 103 KW				
Celica Cabriolet (_T16_) 2.0 GT 10.86-08.90 110 K				
MC 3SGEL 2.0 ltr. 16V				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*529.600*	