

Anziehvorschrift für Zylinderkopf		540.440 passend für / suitable for adaptable à / adaptable a Kia	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
⑦ ③ ② ⑥ ⑩ ⑧ ④ ① ⑤ ⑨				
Anziehen/ Tightening/ Serrage/ Apriete		* 25 Nm 55 Nm 85 Nm		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
MC FE KIA Sportage 2,0i 04.94-08.99 70KW				
MC FE16V KIA Clarus 2,0i 16V 07.96- 98KW KIA Sportage 2,0i 16V 10.00-08.03 94KW KIA Sportage 2,0i 16V 4WD 04.94-08.03 94KW				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*540.440*	