

Anziehvorschrift für Zylinderkopf		540.470 passend für / suitable for adaptable à / adaptable a Mitsubishi	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
⑧ ④ ① ⑤ ⑦ ③ ② ⑥				
Anziehen/ * 30 Nm Tightening/ 70 Nm Serrage/ 110 Nm Apriete				
Zeichenerklärung / Explanations / Explication / Explicacion				
*	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Mitsubishi MC 6G72 V6 3,0 ltr. 104 KW - 210 KW 11.88-04.00 Sigma/ Pajero I/ Pajero II/ 3000 GT 24V 4x4 MC G6AT 3,0 ltr. Mitsubishi Galloper 3,0 ltr.V6 02.99- 104 KW Hyundai Sonata I 3,0i 16V 01.91-10.93 107 KW Hyundai Sonata II 3,0i 16V 05.93-06.98 107 KW				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*540.470*	