

Anziehvorschrift für Zylinderkopf			630.870		 Das Original
Tightening Instructions for Cylinder Head			passend für / suitable for		
Instructions de serrage pour culasse			adaptable à / adaptable a		
Prescripciones de apriete para culatas			Ford		
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo			Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
RIGHT SIDE 1173159 12842610 FRONT LEFT SIDE 12842610 1173159					
Anziehen/ Tightening/ Serrage/ Apriete * ➤ ➤ 30 lb-ft 90° 90° * ➤ ➤ 40 Nm 90° 90°					
Zeichenerklärung / Explanations / Explication / Explicacion					
* ✱ □ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage	emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro	
Motortyp / Engine type / Type de moteur / Tipo de motor					
Ford V10 6.8L 415cid LH E-350 Club Wagon, Excursion, E-250 Econoline E-350 Super Duty 1999-2017 F-250 Super Duty 1999-2004 F-350 Super Duty 1999-2004					
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*630.870*		