

Anziehvorschrift für Zylinderkopf		630.900 passend für / suitable for adaptable à / adaptable a Ford	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
RIGHT SIDE 11 7 3 1 5 9 12 8 4 2 6 10 FRONT LEFT SIDE 12 8 4 2 6 10 11 7 3 1 5 9				
Anziehen/ Tightening/ Serrage/ Apriete * 30 lb-ft ➤ 90° ➤ 90° * 40 Nm ➤ 90° ➤ 90°				
Zeichenerklärung / Explanations / Explication / Explicacion				
	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
	Setzzeit	relaxation time	durée de tassement	tiempo de espera
	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Ford V10 6.8L 415cid RH				
E-350 Club Wagon, Excursion, E-250 Econoline				
E-350 Super Duty 1999-2017				
F-250 Super Duty 1999-2004				
F-350 Super Duty 1999-2004				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*630.900*	