


Anziehvorschrift für Zylinderkopf		798.200		Das Original
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
		⑦①③⑤ ⑥④②⑧ ⑥④②⑧ ⑦①③⑤		
267.660 M 11x1,25x123				
Anziehen/ Tightening/ Serrage/ Apriete	* □ ➤ ➤	98 Nm 40 Nm 93° +/- 3° 93° +/- 3°		
Zeichenerklärung / Explanations / Explication / Explicacion				
* ★ □ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage	emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
CHG left side Mot: 2ZV 2,5 ltr. 130-140 kW (177-190 PS) Renault Latitude				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*798.200*		