


Anziehvorschrift für Zylinderkopf		818.003 passend für / suitable for adaptable à / adaptable a Suzuki	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
 862.810 M 10 x 94				
Anziehen/ Tightening/ Serrage/ Apriete		* 30 - 35 Nm 50 - 55 Nm 70 - 75 Nm		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Mot. G 13 B 1298 ccm 4 Cyl. 63 kW (85 PS), 07/1995> Baleno (EG) Swift SA413, SF413, AA33, AK35				
Mot. G 13 A, 1298/1342 ccm, 4 Cyl., 44/47/50/52 kW (60/64/68/71 PS), 1985>				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*818.003*	