


Anziehvorschrift für Zylinderkopf		920.306 passend für / suitable for adaptable à / adaptable a Honda	 Das Original	
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
 706.120 M 10x1,25x140				
Anziehen/ Tightening/ Serrage/ Apriete	* 30 Nm 68 Nm			
Zeichenerklärung / Explanations / Explication / Explicacion				
*	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
76 Ø Civic EC8 Mot. D13B1 55 kW (75 PS) 1987> EC9 Mot. D14A1 66 kW (90 PS) 1987>1989 ED Mot. D15B ED4,ED7 Mot. D16A6/A7 80 kW (109 PS) 1987> EE4 Mot. D16A6 Concerto HW Mot. D15B2 66 kW (90 PS) 1990>				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*920.306*	